












Using the correct size cuff is important for an accurate reading

To determine what cuff size is appropriate for you, measure the circumference of your upper arm at the midpoint between the shoulder and elbow



	Small UA-279 6.3-9.4"	Medium UA-280 9.4-14.2"	Large UA-281 14.2-17.7"	Small UA-289 6.3-9.4"	Medium UA-290 9.0-14.6"	Large UA-291 12.2-17.7"	Pre-Formed UA-381 9-17"	Smooth Fit UA-392 9.0-14.6"	X-Large UA-282 16.5-23.6"	AccuFit Plus (Wide Range) UA-420 8.6-16.5"
UA-611 					✓	✓				✓
UA-651 					✓	✓				✓
UA-651BLE 					✓	✓				✓
UA-651BLEV-S 				✓						
UA-767PBT-Ci 		✓	✓							
UA-767PBTS-Ci 	✓									
UA-767F Series 					✓	✓				✓
UA-787EJ 	✓	✓	✓				✓			
UA-789AC 		✓	✓						✓	
UA-1030T 				✓	✓	✓		✓		